



Discard Tray Set

Assembly Instructions




**** This product is intended to be assembled using wood glue to ensure its durability and longevity. ****


Step 1:

Separate pieces into their respective piles.

Dice Holder:




Card Holders:



Blue arrows indicate connection points and red arrows highlight correct facing/direction of pieces


Step 2 (Dice Holder):

Attach the Side Wall pieces to the Floor piece as shown.



Step 3 (Dice Holder):


Attach the Front/Back Wall pieces to the Floor and Side Wall pieces as shown.



Dice Holder is now complete.


Step 4 (Card Holder – Discarded Weapons):

Attach the One Side Wall piece to the Card Holder piece, making note they are facing the correct way as shown.




Step 5 (Card Holder – Discarded Weapons):

Attach the Floor piece to the One Side Wall piece, making note they are facing the correct way as shown.




Step 6 (Card Holder – Discarded Weapons):

Attach the Other Side Wall piece to the Floor and Card Holder, making note they are facing the correct way as shown.




Step 7 (Card Holder – Discarded Weapons):

Attach the Back Wall piece to the Floor, One Side Wall and Other Side Wall pieces, making note they are facing the correct way as shown. **Note the top side of the Back Wall piece with more space should be on the same side as the gap between the Card Holder and the One Side Wall pieces.**




Step 8 (Card Holder – Discarded Bunnies):

Attach the One Side Wall piece to the Card Holder piece, making note they are facing the correct way as shown.




Step 9 (Card Holder – Discarded Bunnies):

Attach the Floor piece to the One Side Wall piece, making note they are facing the correct way as shown.




Step 10 (Card Holder – Discarded Bunnies):

Attach the Other Side Wall piece to the Floor and Card Holder, making note they are facing the correct way as shown.



Step 11 (Card Holder – Discarded Bunnies):

Attach the Back Wall piece to the Floor, One Side Wall and Other Side Wall pieces, making note they are facing the correct way as shown. **Note the top side of the Back Wall piece with more space should be on the same side as the gap between the Card Holder and the One Side Wall pieces.**



Follow us on Instagram and Facebook
@mysandboxgaming

Use the following link to watch assembly video:
www.mysandboxgaming.com/assembly-instructions



www.mysandboxgaming.com